

# H2 Stationary Low Volume Insert Kit Instructions

To install the low volume insert kit,

1. Remove the cover from the moisture sensor side of the GrainGage.
2. Open the gate.
3. Disconnect the power cable.
4. Remove the two screws securing the moisture sensor. Leave the moisture sensor in place.



5. From the bottom of the GrainGage, put the low volume insert into place.



6. Using the hardware that came in the kit, place one washer on each screw.



7. From the inside of the hopper, use an Allen wrench to tighten the low volume insert into place. Once tightened the screws will extend through the hopper, and moisture sensor.



8. Secure the moisture sensor with two washers and nuts. Tighten.



9. Connect the power cable.
10. Recalibrate the load cells.

You will need to create new moisture curves for use with the low volume insert.