


- A) Tap Home to exit harvest.
- B) Customize the size of your panels.
- C) Arrange the identifiers in your preferred order.
- D) Map averages.
- E) Tap Start/Cycle when ready to begin collection.
- F) Color coded legend for map.
- G) Diagnostics
- H) Cycle Settings
- I) Navigation
- J) Observations
- K) Graph View
- L) Quad View
- M) Spatial View
- N) List View
- O) Ten Key



- P) The Spatial view (a.k.a. heat map) allows you to see a color coded map of your data.
- Q) Select which attribute you would like to see in the Spatial view. See the *Spatial View* section of [your Mirus manual](#) for details.
- R) Enter the plot size information for yield calculation
- S) Enter grain yield factors.
- T) Set the range of values.

